Honeywell | Home

THE POWER OF **CONNECTED**

D6 PRO Wi-Fi DUCTLESS CONTROLLER

Quick Guide

Display sleep

The controller goes into Display sleep (the screen is dim) after 45 seconds of inactivity. Press **O** to wake up the controller. This button push does not change temperature or settings.

Room temperature

Any time the controller is not being interacted with, the current room temperature is displayed on screen.

Viewing set temperature

Be sure the controller is not in Display sleep, then press **+** or **–** once to view the current set temperature. The set temperature will “pulse” on screen. After a short period of time the screen will change to display the room temperature.

Change temperature

1. Be sure the controller is not in Display sleep, then press **+** or **–** more than once to change the set temperature so it is higher or lower in the current mode.
2. Stop pressing **+** or **–** when you reach the temperature you want.
3. The screen will pulse and then return to the room temperature display.

Warmer

Cooler

Change mode

1. Be sure the controller is not in Display sleep, then press O to change the system mode.
2. Stop pressing O when you reach the mode you want.

The ductless unit will beep when it gets a command from the controller.

Symbol	Mode
☼	Heat mode - the ductless unit warms the space to the temperature shown on the controller.
❄	Cool mode - the ductless unit cools the space to the temperature shown on the controller.
[screen is blank]	Off mode - the ductless unit is turned off

Home and Building Technologies
715 Peachtree Street NE
Atlanta, GA 30308

yourhome.honeywell.com

Need Help?

Go to customer.honeywell.com

Call 1-800-633-3991

® U.S. Registered Trademark
© 2018 Honeywell International Inc.

33-00388—03 M.S. Rev. 02-18
Printed in U.S.A.

33-00388-03