



Press image to zoom

2M USB 2.0 A TO MINI-B CABLE (6.6FT)

Connect your 5-pin mini-USB camera or device to the USB port on your USB hub, PC or Mac®. Works for many camera models from the major brands.

Product # : 27005

Connector 1 : (1) USB-A Male

Connector 2 : (1) USB Mini-B Male

Lengths :

6.6ft

3.3ft

25,935 In Stock ⓘ



Add



print share chat

Product Info[Customer Reviews](#)[Questions & Answers](#)[Distributors](#)[More Choices](#)[Product Description](#)[Product Features](#)[Product Certifications](#)[Product Specifications](#)[Product Uses](#)

Product Description

A handy replacement for a lost cable, or a nice spare for the office. Just plug-and-play for many digital camera models, cellphones, MP3 players, PDAs and other mini-USB devices. This cable provides a transfer rate up to 480 Mbps depending upon the peripheral's USB version, and is ideal for transferring pictures from your digital camera to your PC or Mac. Foil and braid shielding reduces EMI/RFI interference and twisted pair construction helps reduce crosstalk thus ensuring high speed, error-free data transfer.

**WARNING:** Cancer and Reproductive Harm www.P65Warnings.ca.gov

Product Features

- Compatible with most digital cameras
- Perfect replacement or spare cable
- Easily transfer files from a camera to a computer
- Available in lengths up to 2m

Product Certifications

Tap an icon to learn more:



Product Specifications

Length :	2.00 Meter
UPC :	757120270058
Warranty :	Lifetime
Vendor :	C2G
Weight :	0.170 LB

- Supports high speed USB 2.0 devices (480 Mbps), and is backwards compliant with full-speed USB 1.1 (12 Mbps) and low speed USB 1.0 (1.5 Mbps).
- PC and Mac® compatible

Product Uses

Compatible with the following camera models:

- **Canon®** EOS 10D SLR, EOS 300D Digital Rebel SLR, Powershot A10, Powershot A20, Powershot A30, Powershot A40, Powershot A60, Powershot A70, Powershot A80, Powershot A100, Powershot A200, Powershot A300, Powershot G3, Powershot G5, Powershot S30, Powershot S40, Powershot S45, Powershot S50, Powershot S300, Powershot S330, Powershot S400, Powershot SD10, Powershot SD100
- **Casio®** GV-10, QV-4000, QV-5700, QV-R4, QV-R40
- **Concord** Eye-Q 3340z and Eye-Q 4060AF
- **Contax** TVS Digital
- **Cool-Idcam™** Aqua 2100
- **Fujifilm** FinePix S5000 Zoom and S7000 Zoom
- **HP® Photosmart™** 620, 635, 720, 735, 850, 935, 945
- **Kyocera Finecam** L3V, S3L, S5, S5R, SL300R
- **Nikon** Coolpix 2000, Coolpix SQ, D2H SLR, D100 SLR
- **Olympus** C-50 Zoom, C-720 Ultrazoom, C-730 Ultrazoom, C-740 Ultrazoom, C-750 Ultrazoom, C-4000 Zoom, C-5000 Zoom, C-5050 Zoom, C-5060 Zoom, D-380, D-390, D-520 Zoom, D-550 Zoom, D-560 Zoom, D-565 Zoom, E-1 SLR, Stylus Digital 300, Stylus Digital 400, W-10
- **Panasonic** Lumix DMC-FZ1, DMC-FZ10, DMC-LC5, Lumix DMC-LC33, DMC-LC40
- **Pentax** Optio 330rs and Optio 430rs
- **Polaroid** PDC2150, PDC2350, PDC3350
- **Polaroid** iON 230
- **Ricoh** RR30 Caplio
- **Samsung** Digimax 240
- **Sigma** SD9 SLR and SD10 SLR
- **Sony® Cybershot** DCR-IP220, DCR-PC110, DSC-F707, DSC-F717, DSC-F828, DSC-P1, DSC-P2, DSC-P5, DSC-P7, DSC-P8, DSC-P9, DSC-P10, DSC-P20, DSC-P30, DSC-P31, DSC-P32, DSC-P50, DSC-P51, DSC-P71, DSC-P72, DSC-P92, DSC-S75, DSC-S85, DSC-U10, DSC-U20, DSC-U30, DSC-U50, DSC-U60, DSC-V1
- **Sony Mavica** CD200, CD250, CD300, CD350, CD400, CD500
- **Toshiba®** PDR-M700

Info

- About Us
- Order History
- Where To Buy
- More ▾

Service

- Contact Us
- OEM Solutions
- Tech Support
- More ▾

Resources

- Connector Guides
- ConnectXpress
- Drivers & Manuals
- More ▾

Have A Question?

- Get help with **Chat**
- Call C2G **800.506.9607**



